??GPIO??

GPIO GeneralPurpose input/output

GPI GPO GPIO

Jetson Orin Nano□□□　40PIN GPIO□□□□□□

Sysfs GPIO	Name	Pin	Pin	Name	Sysfs GPI
	3.3 VDC *Power*	1	2	**5.0 VDC** *Power*	
	I2C1_SDA *I2C Bus 7*	3	4	**5.0 VDC** *Power*	
	I2C1_SCL *I2C Bus 7*	5	6	**GND**	
144 gpio492	**GPIO9** *AUDIO_MCLK*	7	8	**UART1_TX** */dev/ttyTHS0*	
	GND	9	10	**UART1_RX** */dev/ttyTHS0*	
112 gpio460	**UART1_RTS**	11	12	**I2S0_SCLK**	*50* gpio398
122 gpio470	**SPI1_SCK**	13	14	**GND**	
85 gpio433	**GPIO12** *Alt: PWM*	15	16	**SPI1_CS1**	*126* gpio474
	3.3 VDC *Power*	17	18	**SPI1_CS0**	*125* gpio473
135 gpio483	**SPI0_MOSI**	19	20	**GND**	
134 gpio482	**SPI0_MISO**	21	22	**SPI1_MISO**	*123* gpio471
133 gpio481	**SPI0_SCK**	23	24	**SPI0_CS0**	*136* gpio484
	GND	25	26	**SPI0_CS1**	*137* gpio485

1 ?JetPack 5?????GPIO

1.1 ???????GPIO

??GPIO?????????

□ 31□□□□□□□　　454□ GPIO□□□□　　PQ.06□□□□□

- □□□　root□□□□□　　GPIO□

```
sudo bash


echo 454 > /sys/class/gpio/export
```

- □□　GPIO□□□□□

```
echo in > /sys/class/gpio/PQ.06/direction
```

- □□　GPIO□□□□□□□□　　1□□□□□　　0□□□□

```
cat /sys/class/gpio/PQ.06/value
```

- □□　GPIO□□□□□

```
echo out > /sys/class/gpio/PQ.06/direction
```

- □□　GPIO□□□　1□□□□□　　0□□□□

```
echo 1 > /sys/class/gpio/PQ.06/value
```

□□□□□□□□□□□□□□□

```
#!/bin/bash
trap 'echo PQ.06 > /sys/class/gpio/unexport; echo "GPIO PQ.06 is released"' EXIT

echo "setting GPIO PQ.06"
echo PQ.06 > /sys/class/gpio/export 2>/dev/null

# set Pin output mode
echo out > /sys/class/gpio/PQ.06/direction
```

```
# blink
while true
do
    echo 0 > /sys/class/gpio/PQ.06/value
    sleep 0.5
    cat /sys/class/gpio/PQ.06/value
    sleep 0.5
    echo 1 > /sys/class/gpio/PQ.06/value
    sleep 0.5
    cat /sys/class/gpio/PQ.06/value
    sleep 0.5
done
```

1.2 ??python??GPIO

1.2.1 ??JETSON.GPIO?

- □□□□□□□□□□□□□□□□□□□□□□□□ **conda**□□□□□□□□□□□□□□□ Jetson □□□ GPIO□

```
pip install JETSON.GPIO
```

Jetson GPIO□□□□□□□ I / O□□□□□□□□

- **BOARD**□□□□□□□□ 40□□□□□□□
- **BCM**□ Broadcom SoC □ GPIO □□□ □□ □□
- **CVM**□ CVM/CVB □□□□□□□□□
- **TEGRA_SOC**□ Tegra SoC □□□□□

```
import time
import RPi.GPIO as GPIO

# define pin number
output_pin = 31

# set pin as BOARD mode
GPIO.setmode(GPIO.BOARD)

# set pin mode
GPIO.setup(output_pin, GPIO.OUT)

print("Press CTRL+C to exit")
```

```
curr_value = GPIO.HIGH
try:
    while True:
        time.sleep(1)
        print("pin {} now is {}".format(output_pin, curr_value))
        GPIO.output(output_pin, curr_value)
        # blink
        curr_value ^= GPIO.HIGH
finally:
    GPIO.cleanup()
```

□□□□□□□□□□□□ □□□□

1.3??C/C++??GPIO

- □□ libgpio-dev

```
sudo apt install libgpio-dev
```

□□□□□

```
/**
 * License - MIT.
*/
#include <stdio.h>
#include <stdlib.h>
#include <unistd.h>
#include <gpiod.h>

#define GPIO_CHIP       "/dev/gpiochip0"
#define GPIO_LED        3

int main()
{
    int ret = 0;
    struct gpiod_chip *gpiochip;
    struct gpiod_line *gpioline;

    // Open driver.
    gpiochip = gpiod_chip_open(GPIO_CHIP);
```

```
    if (NULL == gpiochip) {
        printf("Error in gpiod_chip_open.\n");
        ret = -1;
        goto out1;
    }

    // Get gpio.
    gpioline = gpiod_chip_get_line(gpiochip, GPIO_LED);

    if (NULL == gpioline) {
        printf("Error in gpiod_chip_get_line.\n");
        ret = -1;
        goto out2;
    }

    // Set gpio direction.
    ret = gpiod_line_request_output(gpioline, "gpio", 0);

    if (ret != 0) {
        printf("Error in gpiod_line_request_output.\n");
        ret = -1;
        goto out2;
    }

    // Blink.
    for (int i = 0; i < 10; i++) {
        printf("%d times.\n", i);

        gpiod_line_set_value(gpioline, 1);
        sleep(1);

        gpiod_line_set_value(gpioline, 0);
        sleep(1);
    }

    // Release.
    gpiod_line_release(gpioline);

out2:
    gpiod_chip_close(gpiochip);
```

```
out1:
    return ret;
}
```

- □□□□□

```
g++ test_gpio.cc -o test_gpio -lgpiod
```

- □□□□□□

```
./test_gpio
```

2 ?JetPack 6?????GPIO

2.1??libgpiod??GPIO

□ **JetPack 6.2/r36.4.3** □□ NVIDIA□□□□□□□□ sysfs GPIO □□□ /sys/class/gpio□□□□□□□ sysfs □□□ GPIO□□□□□ Linux□□□ **libgpiod** □□ GPIO

- □□□□□□□

```
sudo apt-get install busybox automake autoconf libtool
```

- □□□□□□□□

```
jetson@jetson-desktop:~$ gpioinfo
gpiochip0 - 164 lines:
□line   0:      "PA.00" "regulator-vdd-3v3-sd" output active-high [used]
□line   1:      "PA.01"       unused   input  active-high
□line   2:      "PA.02"       unused   input  active-high
□line   3:      "PA.03"       unused   input  active-high
□line   4:      "PA.04"       unused   input  active-high
□line   5:      "PA.05"       unused   input  active-high
□line   6:      "PA.06"       unused   input  active-high
□line   7:      "PA.07"       unused   input  active-high
□line   8:      "PB.00"       unused   input  active-high
□line   9:      "PC.00"       unused   input  active-high
...........
```

- □□ GPIO □□

```
gpioget $(gpiofind "PQ.06")
```

- □ GPIO □□□□□□□

```
sudo busybox devmem 0x2430070 w 0x004
```

□□□□□□□□□□□□□ □□□□ □□□□□□

- □□□□□□

```
gpioset --mode=wait `gpiofind "PQ.06"`=1
```

- □□□□□□

```
gpioset --mode=wait `gpiofind "PQ.06"`=0
```

2.2 ??python??GPIO

> □ JetPack6 □□□□□□□□□□□□□□□□□□□□ GPIO□□□□□□□□□□□ GPIO

- □ PQ.06 □□□□□□□□□

```
sudo busybox devmem 0x2430070 w 0x004
```

- □□□□□□□ conda □□□□□□□□□□□□□□□□ Jetson □□□ GPIO □

```
pip install JETSON.GPIO
```

- □□□□□□□□□□□□□□□□□□□ JETSON.GPIO □

```
sudo rm -rf /usr/lib/python3*/dist-packages/Jetson
sudo rm -rf /usr/local/lib/python3*/dist-packages/Jetson
git clone https://github.com/NVIDIA/jetson-gpio.git
cd jetson-gpio
sudo pip3 install .
```

Jetson GPIO □□□□□□□ I / O□□□□□□□□

- **BOARD**□□□□□□□□ 40□□□□□□□
- **BCM**□ Broadcom SoC □ GPIO □□□ □□ □□

- **CVM**： CVM/CVB □□□□□□□□□
- **TEGRA_SOC**： Tegra SoC □□□□□

```
import time
import RPi.GPIO as GPIO

# define pin number PQ.06
output_pin = 31

# set pin as BOARD mode
GPIO.setmode(GPIO.BOARD)

# set pin mode
GPIO.setup(output_pin, GPIO.OUT)

print("Press CTRL+C to exit")
curr_value = GPIO.HIGH
try:
    while True:
        time.sleep(1)
        print("pin {} now is {}".format(output_pin, curr_value))
        GPIO.output(output_pin, curr_value)
        # blink
        curr_value ^= GPIO.HIGH
finally:
    GPIO.cleanup()
```

□□□□□□□□□□□□ □□□□

2.3??C/C++??GPIO

> □ JetPack6 □□□□□□□□□□□□□□□□□□□□ GPIO□□□□□□□□□□□ GPIO

- □ PQ.06 □□□□□□□□□

```
sudo busybox devmem 0x2430070 w 0x004
```

- □□ libgpio-dev

```
sudo apt install libgpiod-dev
```

□□□□□

```
/**
 * License - MIT.
*/
#include <stdio.h>
#include <stdlib.h>
#include <unistd.h>
#include <gpiod.h>

#define GPIO_CHIP       "/dev/gpiochip0"
#define GPIO_LED        106

int main()
{
    int ret = 0;
    struct gpiod_chip *gpiochip;
    struct gpiod_line *gpioline;

    // Open driver.
    gpiochip = gpiod_chip_open(GPIO_CHIP);

    if (NULL == gpiochip) {
        printf("Error in gpiod_chip_open.\n");
        ret = -1;
        goto out1;
    }

    // Get gpio.
    gpioline = gpiod_chip_get_line(gpiochip, GPIO_LED);

    if (NULL == gpioline) {
        printf("Error in gpiod_chip_get_line.\n");
        ret = -1;
        goto out2;
    }

    // Set gpio direction.
    ret = gpiod_line_request_output(gpioline, "gpio", 0);
```

```
    if (ret != 0) {
        printf("Error in gpiod_line_request_output.\n");
        ret = -1;
        goto out2;
    }

    // Blink PQ.06
    for (int i = 0; i < 30; i++) {
        printf("%d times.\n", i);

        gpiod_line_set_value(gpioline, 1);
        sleep(1);

        gpiod_line_set_value(gpioline, 0);
        sleep(1);
    }

    // Release.
    gpiod_line_release(gpioline);

out2:
    gpiod_chip_close(gpiochip);

out1:
    return ret;
}
```

- □□□□□

```
g++ test_gpio.cc -o test_gpio -lgpiod
```

- □□□□□□

```
./test_gpio
```

PADCTL????GPIO????

> □□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□ Pinmux□ TRM □□□

PADCTL_A0(PADCTL_G3) 0x02430000
PADCTL_A4(PADCTL_G4) 0x02434000
PADCTL_A16(PADCTL_EDP) 0x02440000
PADCTL_A24(PADCTL_G7) 0x02448000

7 GPIO09 PADCTL_G7_SOC_GPIO59_0 0x30 gpio-492 PAC.06 0x02448030
15 GPIO12 PADCTL_EDP_SOC_GPIO39_0 0x20 gpio-433 PN.01 0x02440020
29 GPIO01 PADCTL_G3_SOC_GPIO32_0 0x68 gpio-453 PQ.05 0x02430068
31 GPIO11 PADCTL_G3_SOC_GPIO33_0 0x70 gpio-454 PQ.06 0x02430070
32 GPIO07 PADCTL_G4_SOC_GPIO19_0 0x80 gpio-389 PG.06 0x02434080
33 GPIO13 PADCTL_G4_SOC_GPIO21_0 0x40 gpio-391 PH.00 0x02434040

□□□ #37
 edit □□□ 10 □□ 2025 06:39:30
 edit □□□ 18 □□ 2025 07:00:05